



# Environmental Mycobacterium

## SAMPLE COLLECTION

For sampling ice, the volume is 500 ml and should be collected as follows:

1. Complete the Chain of Custody form.
2. Use waterproof pen to label bottle with sample location, description, and date.
3. Completely fill two 250 ml bottles with ice.

## SHIPPING

1. Ship the same day samples are collected
2. Sample(s) may be refrigerated (2–8° C) overnight if necessary
3. Place bottles in box with insulated liner.
4. Place completed Chain of Custody in plastic document holder and pack in box.
5. Ship overnight Monday–Thursday only to:  
Special Pathogens Laboratory  
1401 Forbes Ave., Suite 401  
Pittsburgh, PA 15219

Questions? Contact SPL at 412-281-5335